


Piano hinges (continuous hinges)

35003

35004


1/35



Bend



Do not glue



35004 Piano hinges (continuous hinges)
type 2



1/35




Glue




Remove




180°



180°



**piece of wire
0.3-0.4mm**



<http://vmodels-art.com/>
vmodels2015@gmail.com
+38 066 05 08 131